

# **MK2**

## **Installation Manual**

# Table of Contents

Content of package

Installation

    Preparing the projection space

    Installation - Trolley

    Connections

Power on / off

    Power on

    Power off

Adjusting the image

    Projector configuration

    Calibration process


Operating conditions

Maintenance

    Monthly maintenance


    Quarterly maintenance - air filter

    Lamp replacement

**Trolley**

Height: 140 cm (55")


## Content of package




1x Projection module

4K Projector


Fisheye lens



1x CPU



1x CPU power adaptor




1x Connection strip




1x Remote control


Includes: AAA batteries x2




1x Speaker



1x Adjustment knob




4x CPU clip



6x Cable guides

## Content of package




1x Top tray




4x Trolley legs




12x Screws for the top tray




4x Middle tray mounts




1x Middle tray

8x Round screws  
(4x middle tray)  
4x trolley legs


1x Bottom tray




1x Bottom tray lid

4x Trolley wheels  
(2x with brake /  
2x without brake)


## Content of package




1x LAN cable




1x HDMI cable





1x USB – USB-C cable




1x Power cable IEC C5




1x Mini jack cable

1x 5mm Allen Wrench  
1x 2mm Allen Wrench

1x Power cable CEE 7/7



1x Rubber mallet



4x Screw cover clip

# Installation

## Preparing the projection space.



Before proceeding with the installation of the Broomx MK2 immersive projector, please make sure the projection space fulfills the required specifications and that a wired internet connection is available.

Please consult the corresponding documentation from our [help center](#).

Contact our [technical support team](#) for any doubts.

## Installation - Trolley



1 -Screw the four legs to the top tray using the screws included in the pack.



2 - Turn the stand upside-down.


Fit the tray into place by gently tapping the corners with the rubber mallet.

Insert the screws to secure the legs.




4 - Screw in the four brackets for the middle tray.


Place the cover clips on the top tray.




5 - Place the CPU clips in the bottom tray.



6 - Place the CPU and the connection strip inside the tray.




7 - Place the cable guides to one of the rear legs.




8 - Place the lids of the bottom and middle trays.



9 - Put the brakes on the rear wheels.



10 - Remove the levelers from the bottom of the projection module.



11- Position and center the projection module onto the trolley.



12- Secure the projection module to the trolley using the tightening knob.

## Connections

1. Connect the HDMI cable to the “HDMI” port on the CPU.
2. Connect the other end of the HDMI cable to the “HDMI1” input of the projector.
3. Connect the CPU to a router using the LAN cable.
4. Connect the speaker to the projector using the minijack cable.
5. Connect the speaker to the projector using the USB – USB-C cable.
6. Turn on the speaker using the power button.
7. Connect the projector to a power outlet using the power cable.
8. Connect the CPU to a power outlet using the power supply.

Connect and turn on the speaker before turning on the CPU. If a message related to audio output appears, turn the CPU off and then back on with the speaker turned on and connected..

## Power on / off

### Power on

1. Power on the projector using the remote control.
2. Connect a tablet / smartphone / PC to the projector’s WiFi network:
  - Network: **MK#**
  - Password: **broomxnet**
3. Open a web browser and enter the following URL:
  - **<http://broomx.control>**
4. Navigate to the “Sessions” section and select any content for playback.

### Power off

1. Stop the content being played back, or navigate to: Menu > Settings > Standby.
2. Power off the projector using the remote control.
3. Only disconnect from power when transporting the projector to another location. Before disconnecting from power, wait 3 minutes after powering off the projector.

If the connection fails or is unstable, please disable phone data and all automatic connection to other WiFi networks.

# Adjusting the image

## Projector configuration

1. Remove the back panel of the projection module which is held into place by magnets.
2. Reach out over the projector inside the casing until you feel 3 adjustment wheels.
3. Set the image to the widest display using the Zoom wheel.
4. Adjust the Lens Shift slider so that the bottom of the projected image touches the floor.
5. Adjust the Focus wheel until a crisp image is displayed.

Please find [here](#) a video tutorial for projection adjustments.

## Calibration process

1. Power on the projector and connect the control device (tablet / PC / smartphone).
2. In the control interface, navigate in the main menu (top right) to Settings > Projection > Calibrate.
3. Position the red vertical line in the center of the projection wall.
4. Position the red horizontal line so that it is straight and parallel to the floor across the projected surface.
5. If the red horizontal line cannot be leveled low enough, lift the “OffsetY” fader.
6. Disable the “Calibrate” function to save the changes.

## Operating conditions

- Use in dry, clean and ventilated environments.
- Room temperature: 12–28 °C (54–82 °F).
- Ambient humidity: max. 50%.
- Maximum continuous usage time: 8 h.
- For every 2 hours of use, turn off the projector with the remote control for 15 minutes.

# Maintenance

## Monthly maintenance


Clean the casing, lens and floor / ceiling mount using isopropyl alcohol and a soft microfiber wipe.

Do not spray the alcohol directly on the projector's components.

## Quarterly maintenance - air filter

1. Remove the back panel from the projector module which is held into place with magnets.
2. Remove the air filter cover.
3. Remove the air filter from the projector.
4. Clean the filter with a vacuum cleaner, replace with a new filter if it is too obstructed.
5. Position the air filter and press lightly until it fits into place.
6. Place the air filter cover.

Replacement air filter model: **Epson ELPAF54**



## Lamp replacement

The projector's lamp has a lifespan of 4500 hours.

Once it reaches this limit, a message will be displayed.

Please contact us for instructions for replacing the lamp.